

**Gold/GFI-Cluster**

No  
Connection  
||  
**X**

	Cable Label	Cable Class	Cable Style	Circuit Name(s)	Circuit ID & Load / Source Location
					- or - Panel or Device
1	3A-19	Power	14-2/2	3A-19, Outlet for Dishwasher (GFI Out) 3A-49, Outlet for Dishwasher (GFI In)	Gold/CB-Panel
2	3A-53	Power	14-2/2	3A-53, Outlet for Trash Compactor (GFI In) 3A-58, Outlet for Trash Compactor (GFI Out)	Gold/CB-Panel
3	3A-59	Power	14-2/2	3A-59, Outlet for Ice Maker (GFI In) 3A-60, Outlet for Ice Maker (GFI Out)	Gold/CB-Panel
4	3A-61	Power	14-2/2	3A-61, Outlet for Wine Cooler (GFI In) 3A-62, Outlet for Wine Cooler (GFI Out)	Gold/CB-Panel
5	3A-63	Power	12-2/2	3A-63, Outlet for Instant Hot (GFI In) 3A-64, Outlet for Instant Hot (GFI Out)	Gold/CB-Panel