

Cables Into & Out of Panel

v52

Blue/XL-Dim

No Connection X	Cable Label	Cable Class	Cable Style	Circuit Name(s)	Circuit ID & Load / Source Location - or - Panel or Device
New	1G-A36	CL2	18-2	1G-A36, XL Button Backlight - Segment 2D	Green/XL-Dim
2	1G-S02	CL2	22-2	1G-S02, Door	1G-S02 Lounge Closet
3	2F-S01	CL2	22-2	2F-S01, Double Door	2F-S01 Cedar Closet
4	2F-S04	CL2	22-2	2F-S04, Double Door	2F-S04 BR 3 Closet
5	2G-S07	CL2	22-2	2G-S07, Closet Door	2G-S07 BR 2 Closet
X	1G-A31	T'stat	18-2	1G-A31, spare	Yellow/CN-Panel/1
7	1E-XF1	UTP	Cat 5 (XL-B)	1E-X30, Button 1E-F.1 1E-X31, Button 1E-F.2 1E-X32, Button 1E-F.3 1E-X33, Button 1E-F.4	XL Keypad 1E-F
8	1G-C110	UTP	Cat 5 (XL-S)	1G-C110, MCP 2 - Star Chain #2 Bus	Yellow/CN-Panel/1
9	1G-C111	UTP	Cat 5 (XL-R)	1G-C111, MCP 2 - Relay Driver #5 Bus	Yellow/CN-Panel/1
X	1G-C112	UTP	Cat 5e	1G-C112, (spare)	Yellow/CN-Panel/1
X	1G-C113	UTP	Cat 5e	1G-C113, (spare)	Yellow/CN-Panel/1
X	1G-C114	UTP	Cat 5e	1G-C114, (spare)	Yellow/CN-Panel/1
13	1G-XA1	UTP	Cat 5 (XL-B)	1G-X09, Button 1G-A.1 1G-X10, Button 1G-A.2 1G-X11, Button 1G-A.3 1G-X12, Button 1G-A.4 1G-X13, Button 1G-A.5 1G-X14, Button 1G-A.6	XL Keypad 1G-A
14	1G-XA2	UTP	Cat 5 (XL-B)	1G-X15, Button 1G-A.7 1G-X16, Button 1G-A.8	XL Keypad 1G-A
15	1G-XB1	UTP	Cat 5 (XL-B)	1G-X19, Button 1G-B.1 1G-X20, Button 1G-B.2 1G-X21, Button 1G-B.3 1G-X22, Button 1G-B.4 1G-X23, Button 1G-B.5 1G-X24, Button 1G-B.6	XL Keypad 1G-B
X	1G-XB2	UTP	Cat 5 (XL-B)	1G-X25, 1G-B (spare)	XL Keypad 1G-B
17	1G-XC1	UTP	Cat 5 (XL-B)	1G-X01, Button 1G-C.1 1G-X02, Button 1G-C.2 1G-X03, Button 1G-C.3 1G-X04, Button 1G-C.4 1G-X05, Button 1G-C.5 1G-X06, Button 1G-C.6 1G-X07, Button 1G-C.7	XL Keypad 1G-C
18	1G-XC2	UTP	Cat 5 (XL-B)	1G-X08, Button 1G-C.8	XL Keypad 1G-C
19	1G-XD1	UTP	Cat 5 (XL-B)	1G-X26, Button 1G-D.1 1G-X27, Button 1G-D.2 1G-X28, Button 1G-D.3 1G-X29, Button 1G-D.4 1G-X30, Button 1G-D.5 1G-X31, Button 1G-D.6 1G-X32, Button 1G-D.7	XL Keypad 1G-D
20	1G-XD2	UTP	Cat 5 (XL-B)	1G-X33, Button 1G-D.8	XL Keypad 1G-D

Cables Into & Out of Panel

v52

Blue/XL-Dim

No
Connection
||
X

	Cable Label	Cable Class	Cable Style	Circuit Name(s)	Circuit ID & Load / Source Location - or - Panel or Device
Change	1G-XE1	UTP	Cat 5 (XL-B)	1G-X34, Button 1G-E.1 1G-X35, Button 1G-E.2 1G-X36, Button 1G-E.5 1G-X37, Button 1G-E.6 1G-X40, Button 1G-E.3 1G-X41, Button 1G-E.4 1G-X46, Backlight 1G-E	XL Keypad 1G-E
Change	1G-XT1	UTP	Cat 5 (XL-B)	1G-X17, Button 1G-A.7 (Ext) 1G-X18, Button 1G-A.8 (Ext) 1G-X38, Button 1G-E.5 (ext) 1G-X39, Button 1G-E.6 (ext) 1G-X42, Button 1H-A.1 (ext) 1G-X43, Button 1H-B.1 (ext)	White/CN-Panel/7
X	1G-XT2	UTP	Cat 5 (XL-B)	1G-X44, XL Input Transfer (spare)	White/CN-Panel/7
X	1G-XT3	UTP	Cat 5 (XL-B)	1G-X45, MCP2 Input Transfer From LVRB (Future)	Yellow/XL-LVRB
Change	1H-XA1	UTP	Cat 5 (XL-B)	1H-X01, Button 1H-A.1 1H-X02, Button 1H-A.2 1H-X03, Button 1H-A.3 1H-X04, Button 1H-A.4 1H-X05, Button 1H-A.5 1H-X06, Button 1H-A.6 1H-X13, Backlight 1H-A	XL Keypad 1H-A
Change	1H-XB1	UTP	Cat 5 (XL-B)	1H-X07, Button 1H-B.1 1H-X08, Button 1H-B.2 1H-X09, Button 1H-B.3 1H-X10, Button 1H-B.4 1H-X11, Button 1H-B.5 1H-X12, Button 1H-B.6 1H-X14, Backlight 1H-B	XL Keypad 1H-B
Change	1K-XA1	UTP	Cat 5 (XL-B)	1K-X01, Button 1K-A.1 1K-X02, Button 1K-A.2 1K-X03, Button 1K-A.3 1K-X04, Button 1K-A.4 1K-X05, Button 1K-A.5 1K-X06, Button 1K-A.6 1K-X08, Backlight 1K-A	XL Keypad 1K-A
X	1K-XA2	UTP	Cat 5 (XL-B)	1K-X07, 1K-A (spare)	XL Keypad 1K-A
Change	1G-01/02	Power	14-3	1G-01, Recessed Lights 1G-02, Pendant Lights	1G-01 Lounge Bar 1G-02 Lounge Bar
Change	1G-03/05	Power	14-3	1G-03, (Lounge Bar: LV LED Counter Lighting) 1G-05, (Photo Booth: Overhead Lighting)	Blue/GP-Panel
Change	1G-04	Power	14-2	1G-04, (Photo Booth: Front Lighting)	Blue/GP-Panel
32	1G-06/07/08	Power	14-4	1G-06, Recessed Lights 1G-07, Pendant Light 1G-08, Ceiling Fan Light	1G-06 Lounge Sitting Area 1G-07 Lounge Sitting Area 1G-08 Lounge Sitting Area
33	1G-26	Power	14-2	1G-26, Lighting Group #1	Blue/CB-Panel
34	1G-27	Power	14-2	1G-27, Lighting Group #2	Blue/CB-Panel
35	1G-28	Power	14-2	1G-28, Lighting Group #3	Blue/CB-Panel

Cables Into & Out of Panel

v52

Blue/XL-Dim

No
Connection
||
X

Cable Label	Cable Class	Cable Style	Circuit Name(s)	Circuit ID & Load / Source Location	
				- or -	Panel or Device
36	1G-41	Power	14-2 1G-41, Blue Controller Panels #1	Blue/CB-Panel	
				Blue/XL-HVRB	
				Blue/XL-FSCB	
37	1H-01	Power	14-2 1H-01, Recessed Lights	1H-01	Changing Rooms Hall
38	1H-02/04	Power	14-3 1H-02, Recessed Lights 1H-04, Vanity Light	1H-02	Changing Room A
				1H-02	Changing Room A
				1H-02	Changing Room A
				1H-04	Changing Room A
39	1H-03/05	Power	14-3 1H-03, Recessed Lights 1H-05, Vanity Light	1H-03	Changing Room B
				1H-03	Changing Room B
				1H-03	Changing Room B
				1H-05	Changing Room B
40	1K-23	Power	14-2 1K-23, Workbench / Undercabinet Lights	1K-23	Shop
41	2G-07	Power	14-3 2G-07, Vanity Lighting	2G-07	BR 2/3 Bath
42	2G-17	Power	14-2 2G-17, BR 2/3 Bath: Toe-Kick Light	Blue/GP-Panel	
43	2L-12	Power	14-2 2L-12, Shop Door Coach Light	2L-12	Shop Yard
44	2M-08	Power	14-2 2M-08, Coach Lights	2M-08	Walkout Patio
New	2M-18	Power	14-2 2M-18, Walkout Patio: Railing Lighting	Blue/GP-Panel	
46	2M-19	Power	14-2 2M-19, Deck Walk Lighting	2M-19	Open Deck