

Cable Wire Device Connections

Blue/GFI-Cluster

Cable Wires	Circuit ID Circuit Name	Device Name Terminal Wire Count	Device Type Device Terminal Connection
1G-43 To/From: "Blue/CB-Panel" 14-2/2			
White "Neutral"	1G-43 Lounge: Outlet for Dishwasher (Tier 1)	"Lounge: Wine Cooler GFI" 1	GFI, 15A Dead-Front #1 Power In ('Line') / Neutral
Black "Hot"	1G-43 Lounge: Outlet for Dishwasher (Tier 1)	"Lounge: Wine Cooler GFI" 1	GFI, 15A Dead-Front #1 Power In ('Line') / Line
White/Red "Neutral"	1G-44 Lounge: Outlet for Dishwasher (Tier 2)	"Lounge: Wine Cooler GFI" 1	GFI, 15A Dead-Front #1 Power Out ('Load') / Neutral
Red "Hot"	1G-44 Lounge: Outlet for Dishwasher (Tier 2)	"Lounge: Wine Cooler GFI" 1	GFI, 15A Dead-Front #1 Power Out ('Load') / Load
1G-45 To/From: "Blue/CB-Panel" 14-2/2			
White "Neutral"	1G-45 Lounge: spare (Tier 1)	"Lounge: Trash Compactor GFI" 1	GFI, 15A Dead-Front #2 Power In ('Line') / Neutral
Black "Hot"	1G-45 Lounge: spare (Tier 1)	"Lounge: Trash Compactor GFI" 1	GFI, 15A Dead-Front #2 Power In ('Line') / Line
White/Red "Neutral"	1G-47 Lounge: spare (Tier 2)	"Lounge: Trash Compactor GFI" 1	GFI, 15A Dead-Front #2 Power Out ('Load') / Neutral
Red "Hot"	1G-47 Lounge: spare (Tier 2)	"Lounge: Trash Compactor GFI" 1	GFI, 15A Dead-Front #2 Power Out ('Load') / Load
1G-48 To/From: "Blue/CB-Panel" 14-2/2			
White "Neutral"	1G-48 Lounge: Outlet for Ice Maker (Tier 1)	"Lounge: Dishwasher GFI" 1	GFI, 15A Dead-Front #3 Power In ('Line') / Neutral
Black "Hot"	1G-48 Lounge: Outlet for Ice Maker (Tier 1)	"Lounge: Dishwasher GFI" 1	GFI, 15A Dead-Front #3 Power In ('Line') / Line
White/Red "Neutral"	1G-49 Lounge: Outlet for Ice Maker (Tier 2)	"Lounge: Dishwasher GFI" 1	GFI, 15A Dead-Front #3 Power Out ('Load') / Neutral
Red "Hot"	1G-49 Lounge: Outlet for Ice Maker (Tier 2)	"Lounge: Dishwasher GFI" 1	GFI, 15A Dead-Front #3 Power Out ('Load') / Load
1G-50 To/From: "Blue/CB-Panel" 14-2/2			
White "Neutral"	1G-50 Lounge: Outlet for Trash Compactor (Tier 1)	"Lounge: Ice Maker GFI" 1	GFI, 15A Dead-Front #4 Power In ('Line') / Neutral
Black "Hot"	1G-50 Lounge: Outlet for Trash Compactor (Tier 1)	"Lounge: Ice Maker GFI" 1	GFI, 15A Dead-Front #4 Power In ('Line') / Line
White/Red "Neutral"	1G-51 Lounge: Outlet for Trash Compactor (Tier 2)	"Lounge: Ice Maker GFI" 1	GFI, 15A Dead-Front #4 Power Out ('Load') / Neutral
Red "Hot"	1G-51 Lounge: Outlet for Trash Compactor (Tier 2)	"Lounge: Ice Maker GFI" 1	GFI, 15A Dead-Front #4 Power Out ('Load') / Load
1G-52 To/From: "Blue/CB-Panel" 12-2/2			
White "Neutral"	1G-52 Lounge: Outlet for Microwave (Tier 1)	"Lounge: Microwave GFI" 1	GFI, 20A Dead-Front #1 Power In ('Line') / Neutral

Cable Wire Device Connections

Blue/GFI-Cluster

Cable Wires	Circuit ID Circuit Name	Device Name Terminal Wire Count	Device Type Device Terminal Connection
Black "Hot"	1G-52 Lounge: Outlet for Microwave (Tier 1)	"Lounge: Microwave GFI" 1	GFI, 20A Dead-Front #1 Power In ('Line') / Line
White/Red "Neutral"	1G-53 Lounge: Outlet for Microwave (Tier 2)	"Lounge: Microwave GFI" 1	GFI, 20A Dead-Front #1 Power Out ('Load') / Neutral
Red "Hot"	1G-53 Lounge: Outlet for Microwave (Tier 2)	"Lounge: Microwave GFI" 1	GFI, 20A Dead-Front #1 Power Out ('Load') / Load
1G-54	To/From: "Blue/CB-Panel"		12-2/2
White "Neutral"	1G-54 Lounge: Outlet for Instant Hot (Tier 1)	"Lounge: Outlet for Instant Hot GFI" 1	GFI, 20A Dead-Front #2 Power In ('Line') / Neutral
Black "Hot"	1G-54 Lounge: Outlet for Instant Hot (Tier 1)	"Lounge: Outlet for Instant Hot GFI" 1	GFI, 20A Dead-Front #2 Power In ('Line') / Line
White/Red "Neutral"	1G-55 Lounge: Outlet for Instant Hot (Tier 2)	"Lounge: Outlet for Instant Hot GFI" 1	GFI, 20A Dead-Front #2 Power Out ('Load') / Neutral
Red "Hot"	1G-55 Lounge: Outlet for Instant Hot (Tier 2)	"Lounge: Outlet for Instant Hot GFI" 1	GFI, 20A Dead-Front #2 Power Out ('Load') / Load