

<b>RF Dist Amp, TV Ant, 8-port (w/ Supply) (1 of 3)</b>	<b>"TV Ant Dist Amp, Tier 1 (Emerg)"</b>	(Part TBD)	Tag Number 0127
---	--	------------	--------------------

**Input**

**Attic - ^ Master BR: TV Antenna**

RF Dist Amp, TV Ant, 8-port (w/ Supply) #1

Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
4A-R02 4A-R02	RG-6 (QS)	Attic - ^ Master BR: TV Antenna	65 Attic - ^ Master BR (Antenna, TV)	4A-R02	RG-6	Coax Cable	Coax	In Jack

**Output / #1**

*One other connection in panel.*

**TV Ant Tier 1 Feed A**

RF Dist Amp, TV Ant, 8-port (w/ Supply) #1

Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1L-R12 1L-R12	RG-6	TV Ant Tier 1 Feed A	3 This Panel Only	1L-R12	RG-6	Coax Cable	Coax	Out Jack #1

**Output / #2**

*One other connection in panel.*

**TV Ant Tier 1 Feed B**

RF Dist Amp, TV Ant, 8-port (w/ Supply) #1

Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1L-R13 1L-R13	RG-6	TV Ant Tier 1 Feed B	3 This Panel Only	1L-R13	RG-6	Coax Cable	Coax	Out Jack #2

**Output / #3**

**Lakeside Rm: RF (TV Ant)@Cable Port 07**

RF Dist Amp, TV Ant, 8-port (w/ Supply) #1

Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
3A-R01 3A-R01	RG-6	Lakeside Rm: RF (TV Ant)@Cable Port 07	67 Lakeside Rm (Cable Port 07)	3A-R01	RG-6	Coax Cable	Coax	Out Jack #3

**Output / #4**

**Shop: RF (TV Ant)@Cable Port 1K-02**

RF Dist Amp, TV Ant, 8-port (w/ Supply) #1

Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1K-R03 1K-R03	RG-6	Shop: RF (TV Ant)@Cable Port 1K-02	29 Shop (Cable Port 1K-02)	1K-R03	RG-6	Coax Cable	Coax	Out Jack #4

**Power Adapter (120 Vac)**

*One other connection in panel.*

**TV Ant Dist Amp 1 Power Adapter**

RF Dist Amp, TV Ant, 8-port (w/ Supply) #1

Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1L-P08 1L-P08	Plug	TV Ant Dist Amp 1 Power Adapter	3 This Panel Only	1L-P08	Plug	Narrow Spade	Hot	Narrow Spade
				1L-P08	Plug	Wide Spade	Neutral	Wide Spade

**RF Dist Amp, TV Ant, 8-port (w/ Supply) (2 of 3)** "TV Ant Dist Amp A, Tier 2 (Line)" (Part TBD) Tag Number 0424

**Input**

One other connection in panel.

TV Ant Tier 1 Feed A

RF Dist Amp, TV Ant, 8-port (w/ Supply) #2

Source Cable(s)				Source Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1L-R12 1L-R12	RG-6	TV Ant Tier 1 Feed A	3 This Panel Only	1L-R12	RG-6	Coax Cable	Coax	In Jack

**Output / #1**

Theater: RF (TV Ant)@Cable Port 1F-03

RF Dist Amp, TV Ant, 8-port (w/ Supply) #2

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1F-R01 1F-R01	RG-6	Theater: RF (TV Ant)@Cable Port 1F-03	28 Theater (Cable Port 1F-01)	1F-R01	RG-6	Coax Cable	Coax	Out Jack #1

**Output / #2**

BR 5: RF (TV Ant)@Cable Port 1A-01

RF Dist Amp, TV Ant, 8-port (w/ Supply) #2

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1A-R01 1A-R01	RG-6	BR 5: RF (TV Ant)@Cable Port 1A-01	61 BR 5 (Cable Port 1A-01)	1A-R01	RG-6	Coax Cable	Coax	Out Jack #2

**Output / #3**

BR 4: RF (TV Ant)@Cable Port 1B-01

RF Dist Amp, TV Ant, 8-port (w/ Supply) #2

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1B-R01 1B-R01	RG-6	BR 4: RF (TV Ant)@Cable Port 1B-01	57 BR 4 (Cable Port 1B-01)	1B-R01	RG-6	Coax Cable	Coax	Out Jack #3

**Output / #4**

Master BR: RF (TV Ant)@Cable Port 2A-01

RF Dist Amp, TV Ant, 8-port (w/ Supply) #2

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
2A-R01 2A-R01	RG-6	Master BR: RF (TV Ant)@Cable Port 2A-01	51 Master BR (Cable Port 2A-01)	2A-R01	RG-6	Coax Cable	Coax	Out Jack #4

**Output / #5**

Master Bath: RF (TV Ant)@Cable Port 2B-01

RF Dist Amp, TV Ant, 8-port (w/ Supply) #2

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
2B-R01 2B-R01	RG-6	Master Bath: RF (TV Ant)@Cable Port 2B-01	63 Master Bath (Cable Port 2B-01)	2B-R01	RG-6	Coax Cable	Coax	Out Jack #5

**Output / #6**

Study: RF (TV Ant)@Cable Port 2B-02

RF Dist Amp, TV Ant, 8-port (w/ Supply) #2

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
2B-R05 2B-R05	RG-6	Study: RF (TV Ant)@Cable Port 2B-02	47 Study (Cable Port 2B-02)	2B-R05	RG-6	Coax Cable	Coax	Out Jack #6

**Output / #7**

RF Dist Amp, TV Ant, 8-port (w/ Supply) #2

**Fitness Room: RF (TV Ant)@Cable Port 1D-01**

<i>Load Cable(s)</i>				<i>Load Cable Wires</i>				<i>Device Connection</i>
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	
1D-R01 1D-R01	RG-6	Fitness Room: RF (TV Ant)@Cable Port 1D-01 Fitness Room (Cable Port 1D-01)	29	1D-R01	RG-6	Coax Cable	Coax	Out Jack #7

**Output / #8**

RF Dist Amp, TV Ant, 8-port (w/ Supply) #2

**Great Room: RF (TV Ant)@Cable Port 2C-01**

<i>Load Cable(s)</i>				<i>Load Cable Wires</i>				<i>Device Connection</i>
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	
2C-R01 2C-R01	RG-6	Great Room: RF (TV Ant)@Cable Port 2C-01 Great Room (Cable Port 2C-01)	34	2C-R01	RG-6	Coax Cable	Coax	Out Jack #8

**Power Adapter (120 Vac)**

RF Dist Amp, TV Ant, 8-port (w/ Supply) #2

*One other connection in panel.*

**TV Ant Dist Amp 2 Power Adapter**

<i>Source Cable(s)</i>				<i>Source Wires</i>				<i>Device Connection</i>
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	
1L-P01 1L-P01	Plug	TV Ant Dist Amp 2 Power Adapter	3 <i>This Panel Only</i>	1L-P01 1L-P01	Plug	Narrow Spade Wide Spade	Hot Neutral	Narrow Spade Wide Spade

**RF Dist Amp, TV Ant, 8-port (w/ Supply) (3 of 3)** "TV Ant Dist Amp B, Tier 2 (Line)" (Part TBD) Tag Number 0710

**Input**

One other connection in panel.

TV Ant Tier 1 Feed B

RF Dist Amp, TV Ant, 8-port (w/ Supply) #3

Source Cable(s)				Source Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1L-R13 1L-R13	RG-6	TV Ant Tier 1 Feed B	3 This Panel Only	1L-R13	RG-6	Coax Cable	Coax	In Jack

**Output / #1**

Woodside Rm: RF (TV Ant)@Cable Port 06

RF Dist Amp, TV Ant, 8-port (w/ Supply) #3

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
3A-R09 3A-R09	RG-6	Woodside Rm: RF (TV Ant)@Cable Port 06	63 Woodside Rm (Cable Port 06)	3A-R09	RG-6	Coax Cable	Coax	Out Jack #1

**Output / #2**

BR 2: RF (TV Ant)@Cable Port 2G-01

RF Dist Amp, TV Ant, 8-port (w/ Supply) #3

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
2G-R01 2G-R01	RG-6	BR 2: RF (TV Ant)@Cable Port 2G-01	59 BR 2 (Cable Port 2G-01)	2G-R01	RG-6	Coax Cable	Coax	Out Jack #2

**Output / #3**

BR 3: RF (TV Ant)@Cable Port 2F-02

RF Dist Amp, TV Ant, 8-port (w/ Supply) #3

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
2F-R03 2F-R03	RG-6	BR 3: RF (TV Ant)@Cable Port 2F-02	41 BR 3 (Cable Port 2F-02)	2F-R03	RG-6	Coax Cable	Coax	Out Jack #3

**Output / #4**

Screen Porch: RF (TV Ant) @Cable Port 2F-03

RF Dist Amp, TV Ant, 8-port (w/ Supply) #3

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
2F-R08 2F-R08	RG-6	Screen Porch: RF (TV Ant) @Cable Port 2F-03	47 Screen Porch (Cable Port 2F-03)	2F-R08	RG-6	Coax Cable	Coax	Out Jack #4

**Output / #5**

Lounge Entry: RF (TV Ant)@Cable Port 1G-04

RF Dist Amp, TV Ant, 8-port (w/ Supply) #3

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1G-R01 1G-R01	RG-6	Lounge Entry: RF (TV Ant)@Cable Port 1G-04	58 Lounge Entry (Cable Port 1G-04)	1G-R01	RG-6	Coax Cable	Coax	Out Jack #5

**Output / #6**

Kitchen: RF (TV Ant)@Cable Port 2D-01

RF Dist Amp, TV Ant, 8-port (w/ Supply) #3

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
2D-R01 2D-R01	RG-6	Kitchen: RF (TV Ant)@Cable Port 2D-01	48 Kitchen (Cable Port 2D-01)	2D-R01	RG-6	Coax Cable	Coax	Out Jack #6

## Output / #7

## BR 2: RF (TV Ant)@Cable Port 2G-02

RF Dist Amp, TV Ant, 8-port (w/ Supply) #3

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	
2G-R03 2G-R03	RG-6	BR 2: RF (TV Ant)@Cable Port 2G-02	59 BR 2 (Cable Port 2G-01)	2G-R03	RG-6	Coax Cable	Coax	Out Jack #7

## Output / #8

## BR 3: RF (TV Ant)@Cable Port 2F-01

RF Dist Amp, TV Ant, 8-port (w/ Supply) #3

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	
2F-R05 2F-R05	RG-6	BR 3: RF (TV Ant)@Cable Port 2F-01	58 BR 3 (Cable Port 2F-01)	2F-R05	RG-6	Coax Cable	Coax	Out Jack #8

## Power Adapter (120 Vac)

One other connection in panel.

## TV Ant Dist Amp 3 Power Adapter

RF Dist Amp, TV Ant, 8-port (w/ Supply) #3

Source Cable(s)				Source Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	
1L-P09 1L-P09	Plug	TV Ant Dist Amp 3 Power Adapter	3 This Panel Only	1L-P09	Plug	Narrow Spade	Hot	Narrow Spade
				1L-P09	Plug	Wide Spade	Neutral	Wide Spade

**RF Dist Amp, FM Ant, 8-port (w/ Supply)** "FM Ant Dist Amp (Line)" (Part TBD) Tag Number 0131

**Input**

**Attic - ^ Master BR: FM Antenna**

RF Dist Amp, FM Ant, 8-port (w/ Supply)

Source Cable(s)				Source Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
4A-R01 4A-R01	RG-6 (QS)	Attic - ^ Master BR: FM Antenna	56 Attic - ^ Master BR (Antenna, FM)	4A-R01	RG-6	Coax Cable	Coax	In Jack

**Output / #1**

**Lakeside Rm: RF (FM Ant)@Cable Port 09**

RF Dist Amp, FM Ant, 8-port (w/ Supply)

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
3A-R05 3A-R05	RG-6	Lakeside Rm: RF (FM Ant)@Cable Port 09	73 Lakeside Rm (Cable Port 09)	3A-R05	RG-6	Coax Cable	Coax	Out Jack #1

**Output / #2**

**Shop: RF (FM Ant)@Cable Port 1K-02**

RF Dist Amp, FM Ant, 8-port (w/ Supply)

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1K-R05 1K-R05	RG-6	Shop: RF (FM Ant)@Cable Port 1K-02	29 Shop (Cable Port 1K-02)	1K-R05	RG-6	Coax Cable	Coax	Out Jack #2

**Output / #3**

**Study: RF (FM Ant)@Cable Port 2B-10**

RF Dist Amp, FM Ant, 8-port (w/ Supply)

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
2B-R10 2B-R10	RG-6	Study: RF (FM Ant)@Cable Port 2B-10	50 Study (Cable Port 2B-10)	2B-R10	RG-6	Coax Cable	Coax	Out Jack #3

**Output / #4**

**Green Utility Closet: RF (FM Ant)@Cable Port 03**

RF Dist Amp, FM Ant, 8-port (w/ Supply)

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1F-R07 1F-R07	RG-6	Green Utility Closet: RF (FM Ant)@Cable Port 03	50 Green Utility Closet (Cable Port 1F-03)	1F-R07	RG-6	Coax Cable	Coax	Out Jack #4

**Output / #5**

**Mech Room: RF (FM Ant 1)**

RF Dist Amp, FM Ant, 8-port (w/ Supply)

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1L-R03 1L-R03	RG-6	Mech Room: RF (FM Ant 1)	23 White/E-Rack/3	1L-R03	RG-6	Coax Cable	Coax	Out Jack #5

**Output / #6**

**Mech Room: RF (FM Ant 2)**

RF Dist Amp, FM Ant, 8-port (w/ Supply)

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1L-R04 1L-R04	RG-6	Mech Room: RF (FM Ant 2)	23 White/E-Rack/3	1L-R04	RG-6	Coax Cable	Coax	Out Jack #6

**Power Adapter (120 Vac)**

*One other connection in panel.*

**FM Ant Dist Amp Power Adapter**

RF Dist Amp, FM Ant, 8-port (w/ Supply)

<i>Source Cable(s)</i>				<i>Source Wires</i>				<b>Device Connection</b>
<b>Circuit ID</b>	<b>Style</b>	<b>Location &amp; Name</b>	<b>Length &amp; Destination</b>	<b>Cable ID</b>	<b>AWG</b>	<b>Wire Color</b>	<b>Wire Function</b>	
1L-P10	Plug	FM Ant Dist Amp Power Adapter	3	1L-P10	Plug	Narrow Spade	Hot	Narrow Spade
1L-P10			This Panel Only	1L-P10	Plug	Wide Spade	Neutral	Wide Spade

**RF Dist Hub, Sat Ant, 8-port (w/ Supply)** "Sat Radio Ant Dist Amp (Line)" (Part TBD) Tag Number 0133

**Input**

**Roof - ^ Upper Level: Sat Radio Antenna**

RF Dist Hub, Sat Ant, 8-port (w/ Supply)

Source Cable(s)				Source Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
4A-R05 4A-R05	RG-6 (QS)	Roof - ^ Upper Level: Sat Radio Antenna Roof - ^ Upper Level (Antenna, MW/SW)	58	4A-R05	RG-6	Coax Cable	Coax	In Jack

**Output / #1**

**Lakeside Rm: RF (Sat Ant)@Cable Port 09**

RF Dist Hub, Sat Ant, 8-port (w/ Supply)

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
3A-R07 3A-R07	RG-6	Lakeside Rm: RF (Sat Ant)@Cable Port 09 Lakeside Rm (Cable Port 09)	73	3A-R07	RG-6	Coax Cable	Coax	Out Jack #1

**Output / #2**

**Green Utility Closet: RF (Sat Radio Ant)@Cable Port 03**

RF Dist Hub, Sat Ant, 8-port (w/ Supply)

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1F-R08 1F-R08	RG-6	Green Utility Closet: RF (Sat Radio Ant)@Cable Port 03 Green Utility Closet (Cable Port 1F-03)	50	1F-R08	RG-6	Coax Cable	Coax	Out Jack #2

**Output / #3**

**Study: RF (Sat Radio Ant)@Cable Port 10**

RF Dist Hub, Sat Ant, 8-port (w/ Supply)

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
2B-R19 2B-R19	RG-6	Study: RF (Sat Radio Ant)@Cable Port 10 Study (Cable Port 2B-10)	50	2B-R19	RG-6	Coax Cable	Coax	Out Jack #3

**Output / #4**

**Mech Room: RF (Sat Radio Ant 1)**

RF Dist Hub, Sat Ant, 8-port (w/ Supply)

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1L-R05 1L-R05	RG-6	Mech Room: RF (Sat Radio Ant 1) White/E-Rack/3	23	1L-R05	RG-6	Coax Cable	Coax	Out Jack #4

**Output / #5**

**Mech Room: RF (Sat Radio Ant 2)**

RF Dist Hub, Sat Ant, 8-port (w/ Supply)

Load Cable(s)				Load Cable Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1L-R06 1L-R06	RG-6	Mech Room: RF (Sat Radio Ant 2) White/E-Rack/3	23	1L-R06	RG-6	Coax Cable	Coax	Out Jack #5

**Power Adapter (120 Vac)**

One other connection in panel.

**Sat Radio Dist Amp Power Adapter**

RF Dist Hub, Sat Ant, 8-port (w/ Supply)

Source Cable(s)				Source Wires				Device Connection
Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1L-P11 1L-P11	Plug	Sat Radio Dist Amp Power Adapter	3 This Panel Only	1L-P11	Plug	Narrow Spade	Hot	Narrow Spade
				1L-P11	Plug	Wide Spade	Neutral	Wide Spade

<b>Fan &amp; Sensor Kit, Cabinet</b>	"Enclosure Vent Fan & Temp Sensor"	JTB: 1010-3	Tag Number 1101
--------------------------------------	------------------------------------	-------------	--------------------

**Fan Power In**

**White CN/3: Cabinet Fan Drive**

Fan & Sensor Kit, Cabinet

*Output Address =* J2:(2)Y3

Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1L-A146	22-4 (S)	White CN/3: Cabinet Fan Drive	8	1L-A146	22	Red	Power	Fan +
1L-A146			White/CN-Panel/2	1L-A146	22	Black	Signal	Fan -

**Temp Sensor Output**

**White CN/3: Cabinet Temperature**

Fan & Sensor Kit, Cabinet

*Input Address =* J2:(2)X3

Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1L-S11	22-4 (S)	White CN/3: Cabinet Temperature	8	1L-A146	22	White	Select	(Sensor) +
1L-A146			White/CN-Panel/2	1L-A146	22	Green	Signal	(Sensor) -
				1L-A146	22	Shield	Shield	GND

## Spare Cable Group

"Spare Coax Cables"

Tag Number  
na

## Not Connected / #1

Lakeside Rm: RF (spare)@Cable Port 07

Spare Cable Group

Circuit ID Cable ID	Style	Location & Name	Length & Destination
3A-R02 3A-R02	RG-6	Lakeside Rm: RF (spare)@Cable Port 07	67 Lakeside Rm (Cable Port 07)

## Not Connected / #2

BR 2: RF (spare 1)@Cable Port 2G-01

Spare Cable Group

Circuit ID Cable ID	Style	Location & Name	Length & Destination
2G-R02 2G-R02	RG-6	BR 2: RF (spare 1)@Cable Port 2G-01	59 BR 2 (Cable Port 2G-01)

## Not Connected / #3

Fitness Room: RF (spare)@Cable Port 1D-01

Spare Cable Group

Circuit ID Cable ID	Style	Location & Name	Length & Destination
1D-R02 1D-R02	RG-6	Fitness Room: RF (spare)@Cable Port 1D-01	36 Fitness Room

## Not Connected / #4

BR 5: RF (Spare 1)@Cable Port 1A-01

Spare Cable Group

Circuit ID Cable ID	Style	Location & Name	Length & Destination
1A-R02 1A-R02	RG-6	BR 5: RF (Spare 1)@Cable Port 1A-01	61 BR 5 (Cable Port 1A-01)

## Not Connected / #5

BR 5: RF (Spare 2)@Cable Port 1A-01

Spare Cable Group

Circuit ID Cable ID	Style	Location & Name	Length & Destination
1A-R03 1A-R03	RG-6	BR 5: RF (Spare 2)@Cable Port 1A-01	61 BR 5 (Cable Port 1A-01)

## Not Connected / #6

BR 4: RF (spare 1)@Cable Port 1B-01

Spare Cable Group

Circuit ID Cable ID	Style	Location & Name	Length & Destination
1B-R02 1B-R02	RG-6	BR 4: RF (spare 1)@Cable Port 1B-01	57 BR 4 (Cable Port 1B-01)

## Not Connected / #7

BR 4: RF (spare 2)@Cable Port 1B-01

Spare Cable Group

Circuit ID Cable ID	Style	Location & Name	Length & Destination
1B-R03 1B-R03	RG-6	BR 4: RF (spare 2)@Cable Port 1B-01	57 BR 4 (Cable Port 1B-01)

**Not Connected / #8****Theater: RF (Spare)@Cable Port 1F-03**

Spare Cable Group

Circuit ID Cable ID	Style	Location & Name	Length & Destination
1F-R02 1F-R02	RG-6	Theater: RF (Spare)@Cable Port 1F-03	28 Theater (Cable Port 1F-01)

**Not Connected / #9****Master BR: RF (spare 1)@Cable Port 2A-01**

Spare Cable Group

Circuit ID Cable ID	Style	Location & Name	Length & Destination
2A-R02 2A-R02	RG-6	Master BR: RF (spare 1)@Cable Port 2A-01	51 Master BR (Cable Port 2A-01)

**Not Connected / #10****Master BR: RF (spare 2)@Cable Port 2A-01**

Spare Cable Group

Circuit ID Cable ID	Style	Location & Name	Length & Destination
2A-R03 2A-R03	RG-6	Master BR: RF (spare 2)@Cable Port 2A-01	51 Master BR (Cable Port 2A-01)

**Not Connected / #11****Study: RF (spare)@Cable Port 2B-10**

Spare Cable Group

Circuit ID Cable ID	Style	Location & Name	Length & Destination
2B-R11 2B-R11	RG-6	Study: RF (spare)@Cable Port 2B-10	50 Study (Cable Port 2B-10)

**Not Connected / #12****Great Room: RF (spare)@Cable Port 2C-01**

Spare Cable Group

Circuit ID Cable ID	Style	Location & Name	Length & Destination
2C-R02 2C-R02	RG-6	Great Room: RF (spare)@Cable Port 2C-01	34 Great Room (Cable Port 2C-01)

**Not Connected / #14****BR 3: RF (spare 1)@Cable Port 2F-01**

Spare Cable Group

Circuit ID Cable ID	Style	Location & Name	Length & Destination
2F-R04 2F-R04	RG-6	BR 3: RF (spare 1)@Cable Port 2F-01	58 BR 3 (Cable Port 2F-01)

<b>Outlet, Duplex (15A)</b>	"Duplex Outlet, (Emerg)"	(Part TBD)	Tag Number 0288
-----------------------------	--------------------------	------------	--------------------

**Power In (120 Vac)**

**White & Yellow Panels Emerg Power**

Outlet, Duplex (15A)

Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1L-27	12-2	White & Yellow Panels Emerg Power	31	1L-27	12	Black	Hot	Hot
1L-27			Multiple	1L-27	12	White	Neutral	Neutral

**Receptacle / Receptacle #1**

*One other connection in panel.*

**TV Ant Dist Amp 1 Power Adapter**

Outlet, Duplex (15A)

Circuit ID Cable ID	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	Device Connection
1L-P08	Plug	TV Ant Dist Amp 1 Power Adapter	3	1L-P08	Plug	Narrow Spade	Hot	#1 (Hot)
1L-P08			This Panel Only	1L-P08	Plug	Wide Spade	Neutral	#1 (Neutral)

<b>Outlet, Strip (15A)</b>	"Outlet Strip, (Line)"	(Part TBD)	Tag Number 0431
----------------------------	------------------------	------------	--------------------

**Power In (120 Vac)**

**White & Yellow Panels Line Power**

Outlet, Strip (15A)

<i>Source Cable(s)</i>				<i>Source Wires</i>				<b>Device Connection</b>
Circuit ID <i>Cable ID</i>	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	
1L-37	14-2	White & Yellow Panels Line Power	50	1L-37	14	Black	Hot	Hot
1L-37			Multiple	1L-37	14	White	Neutral	Neutral

**Receptacle / Receptacle #1**

One other connection in panel.

**TV Ant Dist Amp 2 Power Adapter**

Outlet, Strip (15A)

<i>Load Cable(s)</i>				<i>Load Cable Wires</i>				<b>Device Connection</b>
Circuit ID <i>Cable ID</i>	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	
1L-P01	Plug	TV Ant Dist Amp 2 Power Adapter	3	1L-P01	Plug	Narrow Spade	Hot	#1 (Hot)
1L-P01			This Panel Only	1L-P01	Plug	Wide Spade	Neutral	#1 (Neutral)

**Receptacle / Receptacle #2**

One other connection in panel.

**TV Ant Dist Amp 3 Power Adapter**

Outlet, Strip (15A)

<i>Load Cable(s)</i>				<i>Load Cable Wires</i>				<b>Device Connection</b>
Circuit ID <i>Cable ID</i>	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	
1L-P09	Plug	TV Ant Dist Amp 3 Power Adapter	3	1L-P09	Plug	Narrow Spade	Hot	#2 (Hot)
1L-P09			This Panel Only	1L-P09	Plug	Wide Spade	Neutral	#2 (Neutral)

**Receptacle / Receptacle #3**

One other connection in panel.

**FM Ant Dist Amp Power Adapter**

Outlet, Strip (15A)

<i>Load Cable(s)</i>				<i>Load Cable Wires</i>				<b>Device Connection</b>
Circuit ID <i>Cable ID</i>	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	
1L-P10	Plug	FM Ant Dist Amp Power Adapter	3	1L-P10	Plug	Narrow Spade	Hot	#3 (Hot)
1L-P10			This Panel Only	1L-P10	Plug	Wide Spade	Neutral	#3 (Neutral)

**Receptacle / Receptacle #4**

One other connection in panel.

**Sat Radio Dist Amp Power Adapter**

Outlet, Strip (15A)

<i>Load Cable(s)</i>				<i>Load Cable Wires</i>				<b>Device Connection</b>
Circuit ID <i>Cable ID</i>	Style	Location & Name	Length & Destination	Cable ID	AWG	Wire Color	Wire Function	
1L-P11	Plug	Sat Radio Dist Amp Power Adapter	3	1L-P11	Plug	Narrow Spade	Hot	#4 (Hot)
1L-P11			This Panel Only	1L-P11	Plug	Wide Spade	Neutral	#4 (Neutral)